



Xtensity 1

USER MANUAL

READ CONTENTS BEFORE USE
LES INNHOLDET FØR BRUK



xtensity.com



Xtensity is a new intimacy massager for men offering a new avenue of pleasure.

Unique push/pull forces stimulate the penis, erectile tissue, erectile muscles and pelvic floor muscles.

SUPERCARGED PLEASURE FORCES



Provide

- DEEPER STIMULATION
- INTENSE PLEASURE
- ENHANCED ERECTION

Xtensity's unique and intense penis stimulation reaches deeper into the male body, igniting erogenous zones.

The patented vacuum-lock cup transfers supercharged push-pull forces efficiently through the penis, engaging erectile tissue and muscles, and reaching deep into the body for a new and intense experience.

XTENSITY - ALL RIGHTS RESERVED



Product information

ON/OFF & light indicator

Turn on: push for 5 seconds

Turn off: push on/off button

Battery level color indicator

2000 mAh battery

14.8V rechargeable Li-ion battery with 4 - 8 hours working time per charge

Brushless Motor

40 mm brushless motor for powerful stimulation

Easy to clean

Detachable cup & sleeve for easy cleaning

7 speed settings

Customize desired pleasure from 500 to 2300 RPM

Safety and quality

CE mark

ISO standard - sex toys

EN standard electrical & massage appliances

Box content





Consult physician before use if medical condition or bleeding disorder.
Stop using if discomfort or pain.
Do not use in wet conditions.

HOW TO USE

1. Choose the right cup that fits the erected penis.



Too big if there is air between cup and penis

2. Attach sleeve & roll it up all the way the track



3. Insert erected penis & roll down sleeve



HOW TO USE

4. Roll down the sleeve its full length & push out excessive air through one-way valve.



How to use 4 - 9

5. Attach cup to massage gun, **push "ON" for 5 seconds** and adjust to desired speed.



Do not use near or in water. This is an electric appliance and wet conditions may result in injury.

HOW TO USE - AFTER USE

1. Push **"OFF"** button and disconnect cup from massage gun



2. Roll down sleeve from the top




3. Clean cup, one-way valve and sleeve

HOW TO USE – CLEANING



WARNING:

Turn "OFF" before cleaning.
Do not submerge the massage gun in water during cleaning, or get water inside the product itself.



CLEANING OF MASSAGER

Clean with antibacterial damp cloth. Ensure product is dry before use.

CLEANING OF CUP & SLEEVE

Only cup, one way-valve and sleeve can be washed with regular water, soap and dried with a cloth. Detach from massage gun before cleaning.



HOW TO USE - CHARGING

Use a CE marked USB/C-port charger with output 5V - 2A and connect the charging cable to Xtensity and the charger.

Place Xtensity with the logo facing upwards. The LED light on the "ON/OFF" button will light up when charging. When fully charged it will show a steady turquoise light.

Xtensity's rechargeable battery is shipped pre-charged and may have fully discharged due to environmental factors. We recommend that you fully charge your Xtensity before first use. The charging process takes about 300 minutes.

Battery level light indicator in the "ON/OFF" button:
In use:

- **Turquoise light** indicates good battery level
- **Red light** indicates charging soon recommended

When charging:

- **Turquoise steady light** indicates fully charged

HOW TO USE - STORAGE

Store the Xtensity product in a dry environment, at room temperature when the product is not in use. Preferably, store it in its discrete storage box. Ensure the product is not weighed down by other items during storage.

Keep the product and accessories away from direct sunlight during storage.

Store your sleeve in its carry case to extend its life. Do not store your sleeve attached onto the cup as it may cause deformation over time.

Keep the user manual for reference.





WARNINGS & CAUTIONS

Consult a physician before using the product if you have any pre-existing medical conditions that may be affected by use of the product

Do not use the product if you use blood-thinning medication or have a bleeding disorder.

Do not let go of the product when it is connected to the penis as bending forces may injure the penis. If you lose the grip risk of injury may occur.

Do not pull or push the product while connected to the penis as blood vessels may be damaged.

Stop using the product immediately if you experience pain, soreness or if the foreskin gets trapped between sleeve and cup.

Do not use or charge the product if it appears damaged or shows any signs of malfunction. Do not use the power supply cord if damaged.

Do not immerse the product in water, nor rinse under the tap. Do not use the product if the motorized part has been exposed to water or liquid with potential to get into the electronics inside.

Do not use the product if malfunctions, a burnt smell or if product heats up above body temperature.



WARNINGS & CAUTIONS

Stop and adjust if air gets in between penis head and cup. Air between reduces stimulation and may also result in friction wounds on the penis head.

Use the product as intended and **avoid prolonged use**. We recommend to not use the product for longer durations than 10 minutes.

Not for internal use/**Not for** anal use.

Frequent use may cause abrasion. If you experience discomfort, **stop** immediately.

Ensure fingers or other body parts do not get pinched between the moving cup and the motorized part.

Do not modify the product or use any of the accessories on other massage guns. Do not use with lubricants or oil.

Do not leave the device ON unattended and **do not** charge the product while sleeping.

Do not disassemble the product.

Product is intended for **adults only**.

If you want to **avoid risks** associated with the listed warnings please return Xtensity before use.

GENERAL INFORMATION - TROUBLESHOOTING

Issue: Device doesn't turn ON

Solution 1: Push the "ON" button constantly for 5 seconds

Solution 2: Xtensity cannot be turned on or used during charging. Disconnect charger to turn ON the product.

Solution 3: Charge your device if battery level is too low. When you first receive your Xtensity, the device may be fully discharged due to environmental factors.

Issue: Inefficient stimulation or cup glide over penis rather than creating efficient push/pull force

Solution 1: Make sure there is no air between the cup and the penis. Make sure penis is fully erect and choose a cup size where there are no room for air between the cup and the sleeve. Push out all excessive air through the one-way valve.

Solution 2: Make sure the one way valve is intact without spill in it.

Solution 3: Make sure the sleeve is correctly attached to the cup and penis. If sleeve is not placed correctly, air may enter between penis and sleeve or cup.

GENERAL INFORMATION

Warranty

The Xtensity product comes with a 1-year warranty from the date of purchase. This warranty is valid as long as the item has been used as intended and all instructions have been followed accordingly. Improper use of the product will invalidate the warranty. The warranty does not cover the sleeve or normal wear and tear like cosmetic deterioration.

Disposal



This product is marked with the WEEE-symbol, which indicates that electronic devices or batteries shall not be disposed of in household waste. Dispose of the product at a suitable local collection site or recycling point. If you have any questions, contact local authorities responsible for waste disposal. By properly disposing of this product, you help to prevent potential negative environmental impacts.

GENERAL INFORMATION - SPECIFICATIONS

Massage gun outer material: Plastic

Buttons: Rubber

Material cup: Plastic (TPV+30%PP)

Material sleeve: Silicone (Medical-Grade Silicone)

Percussive travel length: 7mm

Motor: 40 x 38 mm brushless

Rated power battery: 65W

Rated voltage battery: 14.8V

Battery capacity: 2000 mAh

Rated input from charger: 5V - 2A

Charging time: 5 hours

Working time: 4 - 8 hours

Ingress Protection (IP) rating: IP10 (not waterproof)

Decibel: Below 60 Db

Massage gun size: 242 x 62 mm

Massage gun weight: 584 grams

Manufacturer: Xsome

Po Box 1, Lambertseter, 1101 Oslo, Norway

Email: post@xtensity.com

Website: www.xtensity.com

This issue of the user manual is dated Mar 2025



ISO 3533-2021



Xtensity 1

BRUKER MANUAL

LES INNHOLDET FØR BRUK



xtensity.com

Xtensity er et nytt intimprodukt for menn som tilbyr en ny vei til nytelse.

Unike push/pull-krefter stimulerer penis, erektilt vev, erektil muskulatur og bekkenbunnsmuskler.

SUPERCHARGED PLEASURE FORCES



Provide

- DEEPER STIMULATION
- INTENSE PLEASURE
- ENHANCED ERECTION

Xtensitys unike og intense stimulering av penis når dypere inn i den mannlige kroppen og aktiverer erogene soner.

Den patenterte vakuumpoppen overfører supercharged push-pull-krefter effektivt gjennom penis, aktiverer erektilt vev og muskulatur, og når dypt inn i kroppen for en ny og intens opplevelse.

XTENSITY - ALL RIGHTS RESERVED



Produktinformasjon

ON/OFF & lysindikator

Slå på: Hold i 5 sekunder

Slå av: Trykk ON/OFF

Lysfarge viser batterinivå

2000 mAh batteri

Oppladbart 14,8V Li-ion-batteri med 4 - 8 timers brukstid pr lading.

Børsteløs motor

40 mm børsteløs motor for kraftig stimulering

Enkel å rengjøre

Avtagbar kopp og hylse for enkel rengjøring

7 hastigheter

Tilpass ønsket nytelse fra 500 til 2300 RPM

Sikkerhet og kvalitet

CE-merket

ISO standard - sexleketøy

EN standard - elektriske og massasjeapparater

Innhold i esken



SLIK BRUKER DU XTENSITY



Kontakt lege før bruk ved medisinsk tilstand eller blødningsforstyrrelse. Stopp ved ubehag eller smerte. Ikke bruk i våte/fuktige forhold.

1. Velg riktig koppestørrelse som passer til erigert penis.



For stor hvis det er luft mellom koppen og penis.

2. Fest hylsen og rull den opp helt til enden av sporet.



3. Sett inn erigert penis og rull ned hylsen.



SLIK BRUKER DU XTENSITY

4. Rull ned hylsen til full lengde og press ut overflødig luft gjennom enveisventilen.



2. Juster og press ut overflødig luft gjennom enveisventilen.

5. Fest koppen til massasjepistolen, **trykk på 'ON' i 5 sekunder**, og juster til ønsket hastighet."

Anbefalt brukstid er maksimalt 10 minutter.



Ikke bruk i nærheten av eller i vann. Dette er et elektrisk apparat, og våte forhold kan føre til skade.

HVORDAN BRUKE XTENSITY – ETTER BRUK

1. Trykk på 'OFF' knappen og koble koppen fra massasjepistolen.



2. Rull ned hylsen fra toppen.



3. Rengjør koppen, enveisventilen og hylsen.

HVORDAN BRUKE XTENSITY – RENGJØRING



Advarsel:

Slå av produktet før rengjøring.
Ikke senk massasjepistolen i vann
under rengjøring, og unngå at vann
trenger inn i produktet.

RENGJØRING AV MASSASJEPISTOL

Rengjør med en antibakteriell
fuktig klut. Sørg for at
produktet er tørt før bruk.



RENGJØRING AV KOPP OG HYLSE

Kun koppen, enveisventilen og hylsen kan vaskes med
vanlig vann og såpe og tørkes med en klut.
Fjern dem fra massasjepistolen før rengjøring.



HVORDAN BRUKE XTENSITY – LADING

Bruk en CE-merket USB/C-port-lader med utgang på 5V - 2A, og koble ladekabelen til Xtensity og laderen.

Plasser Xtensity med logoen vendt oppover. LED-lyset på "ON/OFF"-knappen lyser når enheten lades. Når den er fulladet, viser den et konstant turkis lys.

Xtensitys oppladbare batteri leveres forhåndslandet, men kan være helt utladet på grunn av miljøfaktorer. Vi anbefaler at du lader Xtensity helt opp før første bruk. Ladeprosessen tar omtrent 300 minutter.

Batterinivåindikator på "ON/OFF"-knappen:

I bruk:

- **Turkis lys** indikerer god batterikapasitet
- **Rødt lys** indikerer at det snart er behov for lading

Under lading:

- **Turkis stabilt lys** indikerer at enheten er fulladet

HVORDAN BRUKE XTENSITY - LAGRING

Oppbevar Xtensity-produktet i et tørre omgivelser, ved romtemperatur når det ikke er i bruk. Oppbevar det helst i den diskrete oppbevaringsboksen.

Sørg for at produktet ikke blir belastet av andre gjenstander under oppbevaring.

Hold produktet og tilbehøret unna direkte sollys under oppbevaring.

Oppbevar hylsen i den medfølgende oppbevaringsvesken for å forlenge levetiden. Ikke oppbevar hylsen festet til koppen, da dette kan føre til deformasjon over tid.

Brukermanualen anbefales oppbevart i oppbevaringsboksen.





ADVARSLER OG FORHOLDSREGLER

Konsulter lege før bruk av produktet hvis du har eksisterende medisinske tilstander som kan påvirkes av bruken av produktet.

Ikke bruk produktet hvis du bruker blodfortynnende medisiner eller har en blødningsforstyrrelse.

Ikke slipp produktet når det er koblet til penis, da bøyekrefter kan skade penis. Hvis du mister grepet, kan risiko for skade oppstå.

Ikke trekk eller skyv produktet mens det er koblet til penis, da blodårer kan bli skadet.

Stopp bruken umiddelbart hvis du opplever smerte, ømhet eller hvis forhuden blir klemt mellom hylsen og koppen.

Ikke bruk eller lad produktet hvis det ser skadet ut eller viser tegn på feil. Ikke bruk strømledningen hvis den er skadet.

Ikke senk produktet i vann eller skylt det under springen.

Ikke bruk produktet hvis den motoriserte delen har blitt utsatt for vann eller væske som kan trenge inn i elektronikken.

Ikke bruk produktet hvis det oppstår feil, brent lukt eller hvis produktet blir varmere enn kroppstemperatur.



ADVARSLER OG FORHOLDSREGLER

Stopp og juster hvis det kommer luft mellom penishodet og koppen. Luft mellom reduserer stimuleringen og kan også føre til friksjonsskader på penishodet.

Bruk produktet som anvist og **unngå langvarig bruk**. Vi anbefaler å ikke bruke produktet i mer enn 10 minutter av gangen.

Hyppig bruk kan forårsake **slitasje**. Hvis du opplever ubehag, stopp umiddelbart.

Ikke bruk produktet innvortes/**Ikke** bruk analt.

Sørg for at fingre eller andre kroppsdeler ikke kommer i klem mellom den bevegelige koppen og den motoriserte delen.

Ikke modifier produktet eller bruk noen av tilbehørene på andre massasjepistoler. Ikke bruk tilbehør som glid eller oljer.

Ikke la enheten stå på uten tilsyn og **Ikke** lad produktet mens du sover.

Ikke demonter produktet.

Produktet er **kun for voksne**.

Hvis du ønsker å **unngå risikoer** knyttet til de oppførte advarslene, vennligst returner Xtensity før bruk.

GENERELL INFORMASJON - FEILSØKING

Problem: Enheten slår seg ikke på

Løsning 1: Hold "ON"-knappen inne i 5 sekunder.

Løsning 2: Xtensity kan ikke slås på eller brukes under lading. Koble fra laderen for å slå på produktet.

Løsning 3: Lad enheten hvis batterinivået er for lavt. Når du mottar Xtensity for første gang, kan enheten være helt utladet på grunn av miljøfaktorer.

Problem: Ineffektiv stimulering eller koppen glir over penis i stedet for å skape effektiv push/pull-kraft

Løsning 1: Sørg for at det ikke er luft mellom koppen og penis. Pass på at penis er helt erigert, og velg en koppstørrelse hvor det ikke er rom for luft mellom koppen og hylsen. Press ut all overflødig luft gjennom enveisventilen.

Løsning 2: Sørg for at enveisklaffen er intakt og ikke har søl i seg.

Løsning 3: Sørg for at hylsen er korrekt festet til koppen og penis. Hvis hylsen ikke er plassert riktig, kan luft komme inn mellom penis, hylsen eller koppen.

GENERELL INFORMASJON

GARANTI

Xtensity-produktet leveres med 1 års garanti fra kjøpsdato. Garantien er gyldig så lenge produktet har blitt brukt som tiltenkt og alle instruksjoner har blitt fulgt nøye. Feil bruk av produktet vil ugyldiggjøre garantien. Garantien dekker ikke hylsen eller normal slitasje som kosmetisk forringelse.

Gjenvinning



Dette produktet er merket med WEEE-symbolet, som indikerer at elektroniske enheter eller batterier ikke skal kastes sammen med husholdningsavfall. Lever produktet på et egnet lokalt innsamlingssted eller resirkuleringspunkt. Hvis du har spørsmål, kontakt de lokale myndighetene som er ansvarlige for avfallshåndtering. Ved å avhende dette produktet på riktig måte, bidrar du til å forhindre potensielle negative miljøpåvirkninger.

GENERELL INFORMASJON - SPESIFIKASJONER

Massasjepistol ytre materiale: Plast

Knapper: Gummi

Materiale kopp: Plast (TPV+33%PP)

Materiale hylse: Silikon (Medical-grade silicone)

Vandringslengde: 7 mm

Motor: 40 x 38 mm børsteløs

Nominell effekt batteri: 65W

Nominell spenning for batteri: 14,8V

Batterikapasitet: 2000 mAh

Nominelt inngang fra lader: 5V - 2A

Ladetid: 5 timer

Brukstid: 4 - 8 timer

IP-klassifisering: IP10 (ikke vanntett)

Lydnivå: Under 60 dB

Massasje pistol størrelse: 242 x 62 mm

Massasje pistol nettovekt: 584 gram

Produsent: Xsome

Postboks 1, Lambertseter, 1101 Oslo, Norge

E-post: post@xtensity.com

Nettside: www.xtensity.com

Denne brukermanualen er datert Mar 2025



ISO 3533-2021